

## SCHNEIDER ELECTRIC MANUAL STARTERS GV2GV3

GVAD1010

Manual Starter Fault Signalling 2 N/O

- 3 phases
- 63A/690V
- To supply busbar sets GV2G
- To be inserted directly on the top terminals of the devices connected by the busbar sets.
- Connection to the supply cable by screw connectors.



Product description