

Product Information FTS-Series

Calorimetric Flow Switch FTS-141P, FTS-741P

Application

- · Monitoring of flowing liquids in pipes
- The monitor can be used to measure liquids that are aqueous (water content ≥ 50 %), that do not contain oil and that have a medium temperature up to 100 °C (212 °F)

Application examples

- Flow monitoring in pipes from DN 25, e.g., as dry-run protection or for monitoring filters, agitators or cooling loops
- Also suitable for highly pure, aqueous media without particles or solids (e.g. ultra-filtered media, cola)

Hygienic design/Process connection

- · Hygienic process connection with CLEANadapt
- · Conforming to 3-A Sanitary Standard for versions with DIRECTadapt
- · All wetted materials are FDA-conform
- · Sensor completely made of stainless steel
- · Complete overview of process connections: see order code
- The Anderson-Negele CLEANadapt system offers a flow-optimized, hygienic and easily sterilizable installation solution for sensors.

Features

- · CIP cleaning to 100 °C
- · Calorimetric measuring principle with pulsed heating
- · Only one sensor tip, flow-optimized shape
- Insensitive toward temperature shocks, short response time
- \cdot Integrated sensor protection: automatic switch-off at T > 100 °C (switch on hysteresis at T < 95 °C)
- Freely adjustable switch output 15...200/ 300 cm/s = 7...100 %
- $\cdot\,$ Indicator (within head), LED for switching state

Options/Accessories

· Preassembled cable for M12 plug









Flow switch FTS-141P





CLEANadapt

2

Functional principle

The functional principle of the FTS calorimetric flow monitor is based on a temperature sensor mounted on the sensor tip (1) that is periodically heated by a heating element (2). When the medium is stationary, a constant temperature difference ΔT arises between the heated and unheated state. When the medium flows, heat energy is withdrawn from the heated temperature sensor and the temperature difference changes in relation to the flow rate.

In contrast to designs with two separate temperature sensors, of which one is constantly being heated, the measuring principle of the FTS with only one sensor and periodic heating has a lower response time due to the optimized heat transfer and lower heat capacity.

The response time is also significantly influenced by the heat conductivity of the medium. In general, the lower the heat conductivity of the medium, the higher the medium flow rate must be for measurement to be possible.

Schematic drawing

Specification		
Process connection	thread Tri-Clamp	Hygienic G1/2" CLEANadapt tightening torque max. 20 Nm sizes: 1½", 2"
Materials	sensor head/ metal cap process connection (wetted parts) cap (plastic)	1.4308 (CF-8) 1.4435 (316L) Polycarbonate
Surface	product contacting	$R_a \le 0.8 \ \mu m$ (0.8 microns; 32 micro-inch)
Temperature ranges	ambient process / CIP SIP	-2070 °C (-4158 °F) 0100 °C (32212 °F) 140 °C (284 °F) with no function / max. 60 min.
Operating pressure		max. 10 bar (CLEANadapt) max. 60 bar (Tri-Clamp)
Protection class		IP 69 K
Measuring range	FTS-141P FTS-741P	10200 cm/s (6.5 ft/s; 78.7 in/s) 10300 cm/s (9.8 ft/s; 118.1 in/s)
Response time reaction time	in case of temperature leap	5 s max. 10 s at 40 K
Accuracy*	in nominal width range	10 % of full scale DN25DN100
Switch point	freely adjustable FTS-141P FTS-741P hysteresis	7100 % / 15200 cm/s (6.5 ft/s) 7100 % / 15300 cm/s (9.8 ft/s) 10 %
Indicator	7 segment red LED	in % of measuring range output switching state
Electrical connection	cable connector supply voltage current consumption	M12 connector 1.4301 1632 V DC 60 mA (24 V DC)
Output		PNP, max. 200 mA short circuit proof and protected against reverse polarity
Weight	FTS-141P FTS-741P with Tri-Clamp 1½" FTS-741P with Tri-Clamp 2"	410 g 440 g 520 g

*) Reference conditions in case of laminar flow profiles: calibration medium is water at ambient temperature.

Advices | Dimensional Drawings

Measurable media



Notice

The following media can be measured: aqueous liquids (water content \geq 50 %) and liquids that do not contain oil, such as water, milk, beer, fruit juice, CIP media, etc. Gases, oils and media containing oil cannot be measured with the FTS.

Intended use

· Not suitable for applications in potentially explosive areas.

• Not suitable for applications in safety-relevant system parts (SIL).

Dimensional drawing FTS-141P



Dimensional drawing FTS-741P

mechanism that prevents damage:

Three lines appear on the indicator.

Flow monitor FTS has an integrated self-protection

matically switched off with a hysteresis of 5 °C.

At medium temperatures over 100 °C, the sensor is auto-



Dimension Table on FTS-741P						
Order code	Clamp size A [mm / inch]	Immersion length EL [mm / Inch]	Suitable for pipe diameter	Pipe style		
FTS-741P/C10	50.5 / 1½"	49 / 1.93	DN 2540 ISO 1425 1½"	DIN 11866 series A DIN 11866 series B / ISO 1127 DIN 11866 series C / ASME-BPE		
FTS-741P/C20	64/2"	59 / 2.32	DN 50 2"	DIN 11866 series A DIN 11866 series C / ASME-BPE		

PHARMA





PHARMA

Electrical Connection | Operation

4

Electrical connection FTS

- 1: + power supply 16...32 V DC
- 2: Not assigned
- 3: 0 V supply voltage (GND)
- 4: Switch output active





Operation FTS

1. Starting up

- · Install the FTS and make the electrical connections
- Initialization phase: Indicator displays "888" (flashing) for approx. 20 s
- Then the flow rate is displayed as a % of the measuring range
- · The switch output is adjusted according to the set value

2. Menu guidance

- Open the operating mode: Key combination $2x \triangleright$, $2x \triangleleft$, $2x \triangleleft$, $2x \triangleleft$
- Main menu level "SP" (switch point setting) appears on the indicator
- · Navigation in the menu field:
- ▶ to the right,
- \cdot \blacksquare upward, changing the values
- to the left, accepting the new parameter settings, leaving the operating mode

3. Setting the switch point

- Under "SP" in the main menu level, select the editing mode with ▶
- \cdot Move to the first digit with \triangleright ; the digit flashes
- \cdot Enter the desired value with 🔔
- Edit the next digit with $[\mathbb{P}]$; the digit flashes, etc.
- Accept the switch point with 2x
- Leave the menu mode with 1x

4. Setting the switch output

- \cdot Default setting: normally open contact
- If the normally closed function is to be set, proceed as follows:
- · In the main menu level, select "O-C" with [],
- \cdot Open the editing mode with $\left[igstarrow
 ight]$; the indicator shows
- "n.o." (normally open contact, default setting)
- 1x [], the indicator shows "n.c." (normally closed contact)
- · 2x : accept the setting
- · 🔲 : leave the menu mode

FTS-741P Setpoint by Line Size and Velocity

	Velocity m/sec (ft/sec)									
	0.3 (1.0)	0.6 (2.0)	0.9 (3.0)	1.2 (4.0)	1.5 (5.0)	1.9 (6.0)	2.1 (7.0)	2.4 (8.0)	2.7 (9.0)	3.0 (10.0)
Line Size	Flow rate	e l/min (ga	l/min)							
1"	7.2 (1.9)	14.4 (3.8)	21 (5.6)	28 (7.5)	35 (9.4)	43 (11)	50 (13)	57 (15)	64 (17)	72 (19)
1.5"	18 (4.6)	36 (9.2)	52 (14)	70 (19)	87 (23)	105 (28)	123 (32)	140 (37)	158 (42)	180 (46)
2"	33 (8.6)	66 (17)	98 (26)	130 (34)	163 (43)	195 (52)	228 (60)	261 (69)	293 (77)	330 (86)
2.5"	52 (14)	104 (28)	159 (42)	212 (56)	265 (70)	318 (84)	366 (97)	418 (110)	470 (124)	520 (140)
3"	76 (20)	152 (40)	228 (60)	303 (80)	383 (101)	459 (121)	536 (142)	613 (162)	689 (182)	760 (200)
4"	140 (37)	280 (74)	420 (74)	557 (147)	696 (184)	835 (221)	974 (257)	1113 (294)	1252 (331)	1400 (370)
FTS-741P Dis- play / Setpoint	10	20	30	40	50	60	70	80	90	100

Installation

5

FTS-141P Setpoint by Line Size and Velocity						
	Velocity m/sec (ft/sec)					
	0.3 (1.0)	0.6 (2.0)	0.9 (3.0)	1.2 (4.0)	1.5 (5.0)	1.9 (6.0)
Line Size	Flow rate l/min	(gal/min)				
1"	7.2 (1.9)	14.4 (3.8)	21 (5.6)	28 (7.5)	35 (9.4)	43 (11)
1.5"	18 (4.6)	36 (9.2)	52 (14)	70 (19)	87 (23)	105 (28)
2"	33 (8.6)	66 (17)	98 (26)	130 (34)	163 (43)	195 (52)
2.5"	52 (14)	104 (28)	159 (42)	212 (56)	265 (70)	318 (84)
3"	76 (20)	152 (40)	228 (60)	303 (80)	383 (101)	459 (121)
4"	140 (37)	280 (74)	420 (74)	557 (147)	696 (184)	835 (221)
FTS-141P Dis- play / Setpoint	15	30	45	60	75	95

Mechanical connection/Installation

- Ensure that the pipe in which the sensor is installed is completely filled with liquid. Installation in a rising pipe is recommended (in which the direction of flow is upward)
- Note the inlet and outlet dimensions (see drawing DN = pipe cross section)



Conditions for a measuring point according to 3-A Sanitary Standard 74-06

• Only the FTS-741P is suitable for applications requiring 3-A compliant equipment.

• The sensors are designed for CIP-/ SIP-cleaning. Maximum 140 °C / 60 min.

 \cdot Only with 3-A conforming Tri-Clamp connection.

• Mounting position must allow for self draining to be in accordance to current 3-A Sanitary Standard.

Pipe T dimensions for FTS-741P						
			T-Short	Extract		
Tri- Clamp size [inch]	Pipe [inch]	Pipe [mm]	B [mm]	L [mm]		
1½	1½	38.1 x 1.65	34.9	15.9		
2	2	50.8 x 1.65	41.3	15.9		
2	21⁄2	63.5 x 1.65	47.6	15.9		

Pipe T



Note

The Flow Switch FTS-741P is specially designed to work with pipe Ts that have a short extract.

Adapter for FTS-141P

G1/2"	E
Diameter	FHG



Diamete	r	EHG	Varivent		
DN25	1"	EHG-DIN2-25/1/2"	AMV-132/25		
DN40	11⁄2"	EHG-DIN2-40/1/2"	AMV-132/40		
DN50	2"	EHG-DIN2-50/1/2"	AMV-132/50		
DN65	21⁄2"	EHG-DIN2-65/1/2"	AMV-132/65		

PHARMA

Transport/storage

- · Do not store outside
- · Store in an area that is dry and dust-free
- · Do not expose to corrosive media
- · Protect against solar radiation
- \cdot Avoid mechanical shock and vibration
- Storage temperature 0...40 °C (104 °F)
- Relative humidity max. 80 %

Standards and guidelines

 Compliance with the applicable regulations and directives is mandatory.

Notice on CE

- · Applicable directives:
- Electromagnetic Compatibility Directive 2014/30/EU • Compliance with the applicable EU directives is identified by the CE label on the product.
- The operating company is responsible for complying with the guidelines applicable to the entire installation.



Reshipment

- Sensors and process connection must be clean and must not be contaminated with hazardous media and/or heatconductive paste. Note the cleaning information!
- To avoid damage of the equipment, use suitable transport packaging only.





• When using a pressure washer, do not point the nozzle directly at the electrical connections.

Disposal



- Electrical devices should not be disposed of with household trash. They must be recycled in accordance with national laws and regulations.
- Take the device directly to a specialized recycling company and do not use municipal collection points.

Additional Information

7

Conversion table m/s to l/min							
DN	DN 25	DN 40	DN 50	DN 65	DN 80	DN 100	
Flow [m/s]	[l/min]	[l/min]	[l/min]	[l/min]	[l/min]	[l/min]	
0.1	2.9	7.5	11.8	19.9	30	47	
0.2	5.9	15.1	23.6	39.8	60	94	
0.4	11.8	30.1	47.1	79.6	121	188	
0.6	17.7	45.2	70.7	119.4	181	283	
0.8	23.6	60.3	94.2	159.2	241	377	
1.0	29.4	75.4	117.8	199.0	301	471	
1.2	35.3	90.4	141.3	238.8	362	565	
1.4	41.2	105.5	164.9	278.6	422	659	
1.6	47.1	120.6	188.4	318.4	482	754	
1.8	53.0	135.6	212.0	358.2	543	848	
2.0	58.9	150.7	235.5	398.0	603	942	
2.2	64.8	165.8	259.1	437.8	663	1036	
2.4	70.7	180.9	282.6	477.6	723	1130	
2.6	73.6	188.4	294.4	497.5	754	1 178	
2.8	82.4	211.0	329.7	557.2	844	1 319	
3.0	88.3	226.1	353.3	597.0	904	1413	

Conversion table in/s to gal/min

DN		1"	11⁄2"	2"	3"	4"
Flow [in/s]	[m/s]	[gal/min]	[gal/min]	[gal/min]	[gal/min]	[gal/min]
4.0	0.10	0.82	1.84	3.26	7.34	13.05
8.0	0.20	1.63	3.67	6.53	14.68	26.10
16.0	0.41	3.26	7.34	13.05	29.36	52.20
24.0	0.61	4.89	11.01	19.58	44.05	78.30
32.0	0.81	6.53	14.68	26.10	58.73	104.41
40.0	1.02	8.16	18.35	32.63	73.41	130.51
48.0	1.22	9.79	22.02	39.15	88.09	156.61
56.0	1.42	11.42	25.69	45.68	102.77	182.71
64.0	1.63	13.05	29.36	52.20	117.46	208.81
72.0	1.83	14.68	33.03	58.73	132.14	234.91
80.0	2.03	16.31	36.71	65.25	146.82	261.01
88.0	2.24	17.94	40.38	71.78	161.50	287.12
96.0	2.44	19.58	44.05	78.30	176.18	313.22
104.0	2.64	21.21	47.72	84.83	190.87	339.32
112.0	2.84	22.84	51.39	91.36	205.55	365.42
120.0	3.05	24.47	55.06	97.88	220.23	391.52

PHARMA

Order code	CLEANa	dapt G1/2" process connection
FTS-141P	Calor incl. 3	metric Flow Sensor with switch output, CLEANadapt G1/2" process connection material 1.4435 .1 material certificate
•	Cap X P M W	(Plastic without window) (Plastic with control window) (Metal without control window) (Metal with control window)
FTS-141P /	Х	

Order code direct process connection in one piece design

FTS-741P	Calori incl. 3	lorimetric Flow Sensor with switch output, direct process connection material 1.4435 :l. 3.1 material certificate						
	Proces	ss conn	ection					
	C10 C20	C10 (Tri-Clamp 1½") C20 (Tri-Clamp 2")						
		Cap X P M W	(Plastic without window) (Plastic with control window) (Metal without control window) (Metal with control window)					
V	•		Surface finish XX (0.8 μm / 0.8 microns) ↓					
FTS-741P /	C20/	Х/	ХХ					

Accessories

PVC cable with M12 connection made of 1.4305, IP 69 K, unshieldedM12-PVC / 4-5 mPVC cable 4-pin, length 5 mM12-PVC / 4-10 mPVC cable 4-pin, length 10 mM12-PVC / 4-25 mPVC cable 4-pin, length 25 m

PVC cable with M12 connection, nickel-plated brass, IP 67, shielded				
M12-PVC / 4G-5 m	PVC cable 4-pin, length 5 m			
M12-PVC / 4G-10 m	PVC cable 4-pin, length 10 m			
M12-PVC / 4G-25 m	PVC cable 4-pin, length 25 m			

CERT / 2.2 / FTS

factory certificate 2.2 acc. to EN10204 (product-contacting surface only)

PVC cable with M12 connection

Accessories for FTS-741P (not part of standard scope of supply)

Tri-Clamp size	Clamp size A [mm] (see page 3)		0
		Clamp ring Tri-Clamp	Sealing ring Tri-Clamp (EPDM)
1"	50.5	SRC-25	DRC-1"
2"	64.0	SRC-50	DRC-50

50083 / 1.0.1 / 2018-11-09 / AR / EU

NEGELE MESSTECHNIK GMBH Raiffeisenweg 7 87743 Egg an der Guenz Phone +49 (0) 83 33 . 92 04 - 0 Fax +49 (0) 83 33 . 92 04 - 49 sales@anderson-negele.com Tech. Support: support@anderson-negele.com Phone +49 (0) 83 33 . 92 04 - 720